



# TP83P3B Protocol for RS232 004 / Pulse / ccTalk

**XAF5 Support bill 500 、 1000 、 2000 、 5000 、 10000 (CentralAfrican)**

## DIP SW SETTING : 1

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / XAF 500	OFF	OFF	OFF							
	2 Pulse / XAF 500	OFF	OFF	ON							
	3 Pulse / XAF 500	OFF	ON	OFF							
	4 Pulse / XAF 500	OFF	ON	ON							
	5 Pulse / XAF 500	ON	OFF	OFF							
	10 Pulse / XAF 500	ON	OFF	ON							
	20 Pulse / XAF 500	ON	ON	OFF							
	100 Pulse / XAF 500	ON	ON	ON							
	Fast Output Pulse	Lo=50ms Hi=100ms			ON						
★	Slow Output Pulse	Lo=50ms Hi=300ms			OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept XAF 500					ON					
	Reject XAF 500					OFF					
★	Accept XAF 1000						ON				
	Reject XAF 1000						OFF				
★	Accept XAF 2000							ON			
	Reject XAF 2000							OFF			
★	Accept XAF 5000								ON		
	Reject XAF 5000								OFF		
★	Accept XAF 10000									ON	
	Reject XAF 10000									OFF	

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.

## DIP SW SETTING : 2

FUNCTION		SW1	SW2	SW3	SW4
★	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
★	Pulse Protocol (SW3 OFF SW4 OFF)		ON		
	RS232 Protocol (SW3 OFF SW4 OFF)		OFF		
	ccTalk 8 bit			ON	
★	Reserved			OFF	
	Reserved				ON
★	Pulse / RS232				OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch