



TP83P3B Protocol for RS232 004 / Pulse

XAF2 Support bill 5000 · 10000 (CentralAfrican)

DIP SW SETTING : 1

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / XAF 5000	OFF	OFF	OFF							
	2 Pulse / XAF 5000	OFF	OFF	ON							
	3 Pulse / XAF 5000	OFF	ON	OFF							
	4 Pulse / XAF 5000	OFF	ON	ON							
	5 Pulse / XAF 5000	ON	OFF	OFF							
	10 Pulse / XAF 5000	ON	OFF	ON							
	20 Pulse / XAF 5000	ON	ON	OFF							
	100 Pulse / XAF 5000	ON	ON	ON							
	Fast Output Pulse	Lo=50ms Hi=100ms			ON						
★	Slow Output Pulse	Lo=50ms Hi=300ms			OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept XAF 5000						ON				
	Reject XAF 5000						OFF				
★	Accept XAF 10000							ON			
	Reject XAF 10000							OFF			
★	Reserved								ON		
	Reserved								OFF		
★	Reserved									ON	
	Reserved									OFF	
★	Reserved										ON
	Reserved										OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.

DIP SW SETTING : 2

FUNCTION		SW1	SW2	SW3	SW4
★	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
★	Pulse Protocol		ON		
	RS232 Protocol		OFF		
	Straight			ON	
★	Turn Over			OFF	
	Reserved				ON
★	Reserved				OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch