

# TP70/P5 Protocol for ICT106 / Pulse

VND6 Support bill 10000、20000、50000、100000、200000、500000 (Vietnam)

## **DIP SW SETTING: 1**

_	DIP SW SETTING: T										
	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
*	1 Pulse / VND 10000	OFF	OFF	OFF							
	2 Pulse / VND 10000	OFF	OFF	ON							
	3 Pulse / VND 10000	OFF	ON	OFF							
	4 Pulse / VND 10000	OFF	ON	ON							
	5 Pulse / VND 10000	ON	OFF	OFF							
	10 Pulse / VND 10000	ON	OFF	ON							
	20 Pulse / VND 10000	ON	ON	OFF							
	100 Pulse / VND 10000	ON	ON	ON							
	Fast Output Pulse Lo=50ms Hi=100ms				ON						
*	Slow Output Pulse Lo=50ms Hi=300ms				OFF						
	Inhibit level Active Low					ON					
*	Inhibit level Active High					OFF					
*	Accept VND 10,000 / 20,000						ON				
	Reject VND 10,000 / 20,000						OFF				
*	Accept VND 50,000							ON			
	Reject VND 50,000							OFF			
*	Accept VND 100,000								ON		
	Reject VND 100,000								OFF		
*	Accept VND 200,000									ON	
	Reject VND 200,000									OFF	
*	'										ON
	Reject VND 500,000										OFF

#### ★ Menufacture setting

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip Switch 1 to 5 are only for Pulse mode.

### **DIP SW SETTING: 2**

	FUNCTION	SW1	SW2	SW3	SW4
*	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
*	Pulse Protocol		ON		
	ICT Protocol		OFF		
*	Straight			ON	
	Turn Over			OFF	
	Ignore Sensor Problem (Note 1)				ON
*	Acknowledge Sensor Problem (Note 2)				OFF

#### ★ Menufacture setting

Note: (1) Sensor 6 problem occurred ==>> BA will be still in working order.

(The face LED will be Flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop to work when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)